RAPID FIRE

Increase the rate of fire of pistols and semi-automatics. Unload your magazine faster than your opponent.

LEFT TRIGGER RAPID FIRE

Increase the rate of fire of pistols and semi-automatics equipped on your left trigger.

AKIMBO RAPID FIRE

Increase the rate of fire on both triggers while dual wielding your primary weapon.

ADJUSTING YOUR RATE OF FIRE

Create a preferred rate of fire for any weapon.

HOW-TO VIDEOS ON TINYURL.COM/EVIL-PLAYLIST



INSTRUCTION MANUAL







ABOUT PROFILES

Your Evil Controller comes with 20 customizable profiles. They operate just like classes in Call of Duty® Simply select the profile (class) and assign mods (perks).

By default, the first 10 profiles have a fire rate equal to that of their profile number. For example, profile 5 = 5 shots per second. Learn how to modify these defaults under **ADJUSTABLE RAPID FIRE.**

UPON PROFILE ACTIVATION,
PROFILE 1 WILL AUTOMATICALLY BE SELECTED.

20 CUSTOMIZABLE PROFILES —

3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 1

DEFAULT FIRE RATES —

WWW.EVILCONTROLLERS.COM

2 SELECT/CLEAR PROFILE

SELECT A PROFILE

Tap (profile #) of times to choose desired profile. For example, tapping \Box 5 times = profile 5.



CLEAR ALL

Clear all functions in current profile.



Hold for 2 seconds.

3 PROGRAMMING MODS

RAPID FIRE

Increase the rate of fire of semi-automatics weapons.



See Advanced Mods for adjusting rate of fire.

LEFT TRIGGER RAPID FIRE



AKIMBO RAPID FIRE




4 ADVANCED MODS

ADJUSTING YOUR RATE OF FIRE



Hold for 2 seconds.



It's possible for the rate of fire to be so fast that it doesn't register in-game. Slowing automatic weapons down to reduce recoil and increase accuracy can be effective. Features 15,000 speed increments.



5 PROFILE FEATURES

CHECK PROFILE #

Check current profile number. LED will blink # to indicate profile.



TOGGLE PROFILES ON/OFF

Quickly return controller to stock functionality.



LOCK

Prevent mods from being turned on/off during gameplay.

Hold for 3 seconds.

When the light bar pulses, release.



MASTER RESET

Restore the controller to factory settings. Do not perform this operation unless you want to overwrite all of your customized profiles.

This action cannot be undone

Note: Mods must be toggled off in order to perform Master Reset.

Hold for 10 seconds





HOW-TO VIDEOS ON TINYURL.COM/EVIL-PLAYLIST